Easy-Loading Thermodrucker

Mulde Mini GPT-4352 GPT-4352-60

with Controller System A8





Elektronik und Feinwerktechnik GmbH

Modules and devices for input, analysis, display and printing of analog and digital data.

GeBE Document No.: SMAN-E-627-V0.92 Printed: 05.10.2009 Status: 05.10.2009 German: SMAN-D-628

Preliminary

Operating Manual

GeBE Contacts

Printers: GeBE Elektronik und Feinwerktechnik GmbH • E-Mail: sales.ef@gebe.net • www.gebe.net Keyboards: GeBE Computer & Peripherie GmbH • Email: sales@tastaturen.com • www.tastaturen.com Internet Applications: www.gebe.net

The GeBE logo is a registered trademark of GeBE Elektronik und Feinwerktechnik GmbH. All other brands named in this brochure are properties of the respective companies. Errors and changes reserved. The technical data given are non-committal information and do not represent any assurance of certain features. Our terms of payment and delivery apply. Copyright © 2009 GeBE Elektronik und Feinwerktechnik GmbH.

All rights reserved.

GeBE Elektronik und Feinwerktechnik GmbH
Beethovenstr. 15 • Germering • Germany • www.GeBE.net
Phone:++49 (0) 89/894141-0 • Fax:++49 (0) 89/8402168 • email: sales.ef@gebe.net

2 Contents

1 Contents

2	Safety Instructions	3	11	Status Signals	13
3	Packing List	4	12	Service and Maintenance	14
3.1	Options / Accessories	4			
			13 T	roubleshooting and Recovery	14
4	Options for Installation	5			
4.1	Installation in a Front Panel	5	14	CE Certification	15
4.2	Partial Installation in a Plastic Enclosure	5			
4.3	Examples for Installation and Applications	5	15	Technical Data	16
5	Connecting the Printer	6	16	Mechanical Dimensions	16
5.1	Connecting the Voltage Supply	6			
6	Setting up the Printer	7			
6.1	Setting up the Printer through Toolbox	7			
6.2	Firmware Download	7			
7 I	nterfaces				
7.1	Serial Interface	8			
7.1.1	Serial Interface RS232 (V.24) at Connector J2	8			
	Timing of the Serial RS232 /TTL Interface	8			
7.2	USB Interface	9			
8 K	ey Function	10			
9	Operation and Maintenance	11			
9.1	Which Thermal Paper is Suitable?	11			
9.2	Maintenance, Cleaning	11			
10	Character Sets	12			
10.1	Font Sizes	12			

Safety Instructions

2 Safety Instructions



Safe operation of this device is only warranteed, if the instructions in this operating manual have been complied with. The appropriate application and use in accordance with the operating instructions is binding for product liability and product warranty. Attempts by the customer to repair the device will make all warranty claims null and void. With technical questions, please contact GeBE Technical Support.

For installation: Always disconnect system power supplies.

Only use manufacturer's parts and accessories. Make sure that the printer is protected against electrical surges in accordance with EN/IEC 60950.

 The device may only be opened or repaired by authorized personnel. Never open the device or carry out repairs yourself. Always contact an authorized technical servicer.

You can find all necessary service information in the • It is no longer possible to safely operate the device, if: chapter "Service and Maintenance".

- Before the device is turned on, make sure that the system voltage of your installation matches the supply voltage of the device. The device characteristics are printed on the name plate and in the technical data.
 - The name plate is located on the underside of the device.
 - For the technical data refer to chapter 15.
- The peripheral devices that are connected to the interfaces and the DC circuits of this device have to cordance with EN/IEC 60950.
- Switching off the device does not completely disconnect it from the power supply. Your device is only dis- • We expressly point out that the appropriate application connected completely, when the power is unplugged.
- Please make sure that the power supply cable is run in such a way that nobody trips over it, and it cannot be damaged by other devices.



- During operation, surfaces in the surrounding area of the print head may heat up. Therefore, direct contact with the print head must be avoided to prevent burning accidents. Do not put heat sensitive objects close to this heat source.
- Avoid constant high humidity and condensation. Protect the device from being splashed and from coming in contact with chemicals.
- Only use spare parts and accessories supplied or authorized by GeBE. The use of unauthorized parts or accessories may considerably affect the function and safety of the device. All parts included are listed in the chapter "Packing List", while the original accessories are listed in the chapter "Parts and Accessories ".



- - the housing has been damaged due to mechanical overload
 - moisture reached the inside of the device
- smoke is coming from the inside of the device
- the power supply cord is damaged
- the device stopped working properly
- It is prohibited to operate the device, if the housing is damaged.

Unplug or turn off the device immediately, when such a meet the requirements for low safety voltage in ac- failure occurs, and contact your customer service. See chapter "Service and Maintenance".

> and use in accordance with the operating instructions in this manual and on the device itself is binding for product liability and product warranty.

3 Packing List

Article No.	Printer Name		Interfaces				Features	
		RS232, V.24	USB	TTL		CPL: 24 or 48	Color Anthracite RAL7016	
12543	GPT-4352-LV-92-24-USB-WINXP-at		Х			Х	Χ	
12986	GPT-4352-LV-92-24-USB-WINCE-at		Х			Х	Х	
12622	GPT-4352-LV-92-24-V.24-at	Х		Х		Х	Х	
12429	GPT-4352-60-LV-92-24-USB-WINXP-at		Х			Х	Х	
12985	GPT-4352-60-LV-92-24-USB-WINCE-at		Х			Х	Х	
12480	GPT-4352-60-LV-92-24-V.24-at	Х		X		Х	Х	



www.thermalpaperbox.com



Please check during the unpacking process that all parts have been delivered completely and undamaged. Make sure to remove all parts from the packaging material. Claims for damages caused during transport can only be asserted, if the carrier is informed without delay. Please prepare a survey report and send it back to the supplier along with the damaged part.

All Easyload Thermal Printers GPT-4352/ GPT-4352-60 Starter Sets contain:

- Thermal paper, 5 rolls: GPR-T01-058-031-007-060A resp. GPR-T01-058-060-007-060A for GPT-4352-60
- Operating manual: SMAN-E-627

3.1 Options / Accessories

•		
Installation Aids GPT-4352		
 GMS-4352-3HE-18TE 3HE 	3U front panel for 19" racks ,18U width	(Art. 11415)
• GMS-4352-96x96	front panel for DIN housings	(Art. 11414)
Installation Aids GPT-4352-60		
 GMS-4352-60-3HE-18TE 	3U front panel for 19" racks ,18U width	(Art. 12610)
Paper		
• GPR-T01-057-031-007-060A	standard 5 years	(Art. 11347)
• GPR-T151-057-031-007-120A	unending paper	(Art. 12428)
• GPR-T151-057-031-012-120A	52x51labels	(Art. 12698)
• GPR-T101-057-031-007-060A	standard 10 years	(Art. 12032)
• GPR-T251-057-031-007-060A	standard 25 years	(Art. 12033)
• GPR-T01-057-060-007-060A	standard 5 years	(Art. 12410)
• GPR-T151-057-060-025-120A	52x51labels	(Art. 12542)
• GPR-T151-057-060-025-120A	unending paper	(Art. 12984)
• GPR-T101-057-060-012-060A	standard 10 years	(Art. 12982)
• GPR-T251-057-060-012-060A	standard 25 years	(Art. 12983)
Connection cable		
• GKA-410-1-250	Power supply cable ST (7pin) 250 mm, open ended	(Art. 11353)
• GKA-414-1-500	Serial cable RS232/TTL	(Art. 11387)
• GKA-406-2-1000	Round cable RS232 Sub-D socket 9pin. 1.0 m	(Art. 11352)
• GKA-570-2-2000	USB cable 2.0 m	(Art. 12872)
Power supply/Power cable		
• GNG-6VDC-2,5VA	Wall power supply for direct voltage supply	(Art. 12290)
• GKA-430-2-250	Power supply cable chargin socket/con	(Art. 11447)
• GNG-5V-5A-AC	Power supply open frame	(Art. 10473)
• GKA-352-2-1500	Power cable 3p. 1,5 m	(Art. 11002)
• GKA-410-1-250	Power supply cable one end open 7p. 250 mm	(Art. 11353)
 GNG-6,5V-3A-(10-36)VDC 	DC/DC converter input (10-36) VDC output 6.5 VDC	(Art. 11451)
• GKA-284-1-500	Power supply cable 2p. 0,5 m wire end sleeve	(Art. 10414)
• GKA-435-2-110	Cable connection converter/con 7p. 110 mm	(Art. 11466)
• GNG-6,5V-3A-(10-36)VDC	DC/DC converter input (10-36) VDC output 6.5 VDC mounted	(Art. 12618)
• GKA-284-1-500	Power supply cable 2p. 0.5 m wire end sleeve	(Art. 10414)
		•

4 Options for Installation


4.1 Installation in a Front Panel

The printer GPT-4352 in its plastic housing can be easily installed with only two screws in a simply created cutout of a front panel with up to 4 mm thickness. The contact surface is plane. The plastic housing has a 1 mm wide flange on all four sides covering the small gap between front panel surface and plastic housing.

The plastic housing is pushed into the cutout **from the outside**, where it is then screwed tight to two tabs.

The two drill holes have a diameter of 2.8 mm, allowing the use of M2.5 screws.





4.2 Partial Installation in Plastic Enclosure

As shown in the drawing on the left, the printer housing can also be installed in the flange of an enclosure. This version has the part of the plastic housing containing the paper roll protrude from the enclosure, leaving more space inside the enclosure for the installtion of other components.

In order to facilitate the installation in various shapes of enclosures, the exterior wall of the paper storage was left flat underneath the contact flange. About half of the paper storage compartment up to the tilted slot for the insertion of the mounting link can be used, so the plastic housing may extend beyond the enclosure by up to about 19 mm.





4.3 Examples for Installation and Applications

As these images show, this printer has an almost unlimited array of installation options.

The advantage of the compact thermal printer module is that it allows the convenient Easyload Technology to be used for applications with smaller production quantities.

GeBE also offers the matching paper rewinder module for the printer module. As illustrated above, a printer with a presenter port can be placed in a DIN switchboard housing.

The plastic housing is also used in the miniature printer series POCKET from GeBE. It is ideal for handheld computer with an attached print station.

Options for Installation

5 Connecting the Printer



During installation:

Always disconnect the power!




Attention

Avoid reverse polarity of connections, which would cause immediate damage to the printer. Carefully check the power supply connection after the wiring is completed before you turn on the power.

5.1 Connecting the Voltage Supply (1)

The printer can be operated with fixed voltage from a power supply unit. Through the voltage supply connection, the printer can be supplied with voltages between 4.5 V and 6.6 V. The matching logic voltage is generated on the circuit board. The included power supply cable GKA-410 connects to connector J4 (3 red wires for +4.5 to 6.6 VDC, 3 black wires for ground, and a white wire for an NTC 6.8 kOhm of a Ni-MH battery). In simple power connections, the white cable remains without a function. It is recommended to keep the length of the cable as short as possbile. If the cable is too long, the high wire resistance will result in a bad print image, or can even cause damage to the printer.



Labeling:

- 1 Connection voltage supply
- 2 Connection USB
- 3 Connection serial

6 Setting up the Printer through Toolbox

6.1 Setting up the Printer through Toolbox (PC Software) In Preparation

6.2 Firmware Download

The controller has an option to update firmware and/or font, and batch files through the USB or RS232 interface. In RS232 mode, the update can only be carried out through the transfer setting 115200, n, 8, 1.

All control commands required for the download are already integrated in an update file, which only has to be sent to the controller. The controller will load the file and automatically save it in its program memory (flash).

After the successful transfer and programming process, the printer will automatically restart.

Should an error occur during the download process, the controller will remain in download mode and wait for a new download process to start.

If valid firmware is available when the controller voltage is connected, the boot loader of the controller will first check, whether paper is inserted. If this is the case, the printer software will be started immedately. If no paper is insterted, the boot loader will wait for an update for about 5 seconds. Once update data are recognized, the bootload process is started, or the printer firmware is started after 5 seconds.

The baud rate of the printer is now set to the value specified by the printer parameters. Font or firmware update files for downloading are available on the Internet or on request.

Using the Boot Loader in the Field:

- * Connect printer to serial interface of PC.
- * Set RS232 of PC to 115.2 Kbaud.
- * Remove paper roll from the printer (programming recognition for the boot loader).
- * Reset printer.
- * Within 5 seconds, send boot file from PC to printer.
- * Boot update will take about 3 5 seconds.

A restart will follow after the end of the program update. The printer will automatically perform a reset. After that, the printer can be used normally. The baud rate of the printer is now set to the value specified by the printer parameters.

Serial Interface

7 Interfaces

7.1 Serial Interface

RS232 Interface

The included interface cable connects directly to an RS232 connection (COM interface of a PC). A cable with five individual wires that are open ended on one end is available as an option.

TTL Interface

For OEM, a special version with 3.3V TTL levels can be realized on request.

7.1.1 Serial Interface RS232 (V.24) at Connector J2

Connector at the printer: JST-SH (5pin).

Cable: GKA-406: The opposite end has a 9pin SUB-D socket.


The assignment is a 1:1 match with the serial interface of the PC. Please note that with some interfaces, the DSR and DCD have to be terminated.

PIN Assignment

Pin	Signal	In- put/ Out- put	Comment	Assignment Cable GKA-406 D- SUB 9Pin	1 1 1 1 1 1 1
1	GND signal	GND		5	
2	TXD	I	Print data	3	
3	RXD	0	Error messages and Xon/Xoff messages	2	
4 se- lectabl	: RTS +4.5V digital		Handshake input of the controller (Standard: wake-up function) Supply for external adapters	7	
e *)	+4.5V - 6.6V power	0	Supply for external adapters	, , ,	, , , , , , , , , , , , , , , , , , , ,
5	CTS	0	If the level is logic-true, the controller can receive data.	8	
*) Selec	table through resistors.	Please co	ontact us with your inquiry.	1.4.6.9) = NC

7.1.2 Timing of the Serial RS232 /TTL Interface

The default timing is shown in the diagram below.



Signal	Level on TTL interface	Level on RS-232 interface
"1" (Mark)	+5V (TTL-level)	-3V12V
"0" (Space)	0V (TTL-level)	+3V +12V

Serial Data Format Standard:

- 115200 baud
- · 8 data bits
- non-parity bit
- 1 stop bit

Selectable Data Formats

- 1,200; 2,400; 4,800; 9,600; 19,200; 38,400; 57,600; 115,200; 230,400 and 460,800 baud
- 7/8 data bits
- · odd, even, non-parity bit
- 1, 2 stop bit


7.2 USB Interface

USB Printer Class

The USB device class is "Printer Class".

When plugged in, the PC will report "USB printer support" and install a "USB001"USB port.

Either the standard printer driver of the "system78" or the port monitor can be used. During installation of the printer driver, it can be easily guided to the USB port.





Windows XP and Windows CE handle the numeration of a printer differently. Therefore, the printer must be configurated to the operating sys-Attention tem before delivery.

8 Button Functions

Description of the Button Functions

The buttons have different functions depending on the status – normal operation or print settings menu.

The time for which the buttons are held down also determines functionality.


FEED / ENTER (1)

This button wakes up the printer from the sleep mode and transports the paper forward.

When the feed button is pressed, the printer will first feed one line of the set font. If the button is held down for more than two seconds, it will feed continuously.

Self Test

By starting a self test printout, the printer functions can be tested. For this purpose, the FEED button (1) has to be held down for at least three seconds, when it is pressed to reactivate the printer from power-OFF. The interfaces are not tested at this time. Software version and character set are printed. For OEM, special printouts can also be activated during the self test.



Operation and Maintenance

9 Operation and Maintenance

9.1 Which Thermal Paper is Suitable?

The printer is specified for a paper width of 57.5 ± 0.5 mm, 60 g/m^2 paper thickness. GeBE is offering suitable paper rolls. Other papers may cause failures.

Thermal papers that are resistant against water, grease, or alcohol are available for special applications. We will gladly assist you in selecting the right thermal paper for your purposes.

Which side of the thermal paper can be printed on?



Usually, the printable side is the one on the outside of the paper roll. When in doubt, try the finger nail test: Quickly run the tip of a finger nail across the paper, applying pressure. The friction heat will cause blackening on the thermo-sensitive side.

How do I insert the paper?

Use 57.5 mm \pm 0.5mm wide paper with outside coating, with a roll diameter of 31 mm for the GPT-4352 and 60 mm for the GPT-4352-60.

Standard GPT-4352: GPR-T01-058-031-007-060A

Standard GPT-4352-60: GPR-T01-058-060-007-060A

- **1.** Unwind about 10 cm of paper from the roll. Keep the layers wound tightly.
- **2.** Open the printer lid by pressing the LEVER inside the lid slightly upwards. The print roll is lifted from the printer mechanism together with the lid. The lid is now easily opened up.
- 3. Insert the paper roll in the paper compartment, so the outside shows toward the printer mechanism. Only this outside can be printed on.
- 4. Close the lid applying strong pressure. You will hear it snap in, and you will now be able to tear the paper at the tear-off edge without the lid reopening or the paper sliding through the print head.



9.2 Maintenance, Cleaning

After larger print jobs, depending on the paper quality and adverse environmental conditions, it may be necessary to clean print head, sensor, and platen roll, especially, if some areas are no longer printed properly.

- Open the paper supply lid and remove the paper roll.
- Loosen dirt particles at paper, sensor, and tear bar with a small brush.
- Blow forcefully into the paper supply compartment in order to remove coarse dust.
- Soak cotton swab with isopropanol (IPA) and clean the print head, or use print head cleaning pen / cleaning card.
- Other stubborn debris may also be removed with a cotton swab (IPA).



Never use sharp objects for cleaning. This may damage the print head.











10 Character Sets



The controller has one or multiple 8x16 pixel sized character sets. Through a font update at the factory, these can be replaced with a different font of the same size. Other font sizes are NOT possible.

0123456789ABCDEF ╚█♥┆┋ै♦०□०♦░ै♀♪∏♡ ▶◀¢‼╥श€⊈↑↓→←╚┿▲▼ ! "#\$%&`()*+.-./ 30123456789::<=>? |@ABCDEFGHIJKLMNO |PQRSTUVWXYZ[\]^ abcdefahijklmno parstuvµxyz{¦}∼ |Ђѓ,ѓ"…†‡ ‰Љ∢ЊќЋЏ **ի''""** - - _ ™љ> եմ իս -ÿÿ]¤Ґ¦§Ё©€«¬=®ї ľ±lirµ¶·ë№e»|Ssï с∣АБВГАЕЖЗИЙКЛМНОП |РСТУФХЦЧШЩЪЫЬЭЮЯ абвглежзийклмноп рстуфхцчшщъыьэюя

10.1 Font Sizes

The number of printable characters per line depends on the physical features of the printer used. Below are some examples:

Font	384Dots/Line	Breite	Height
Small Font (8x16)	48 C/Line	normal	normal
Low Font (16x16)	24 C/Line	double	normal
Narrow Font (8x32)	48 C/Line	normal	double
Normal Font (16x32)	24 C/Line	double	double
Wide Font (32x32)	12 C/Line	quadruple	double
High Font (16x64)	24 C/Line	double	quadruple
Large Font (32x64)	12 C/Line	quadruple	quadruple
Xlarge Font (64x128)	6 C/Line	eightfold	eightfold

11 Status Signals

LED "STATUS" (green) (4)

The STATUS-LED glows permanently green, when everything is okay. It flashes to signal a failure. During the fast charging process, the STATUS-LED will flash green, while it will glow green permanently during trickle charge.

Status Signals of the Printer through the Interfaces

In addition to the optical status signals through the LEDs on the control panel of the printer, some signals are sent through the serial interface. Most are individual ASCII characters that are evaluated by the host computer.

Whenever an error occurs, the status LED will flash 1:1

To avoid that old unfinished print orders immediately start printing after completion of the Easyload mechanism, causing a paper jam, there is a built-in error lag of about 2 seconds. Should errors occur, the printer mechanism will be blocked for two seconds after the last error has been cleared. This gives the user enough time to close the lid without having the printer start immediately.

THE DIE	s are defined	as follows.		Status Byte 1	
	Bit	LED	Status	0	1
	0	on	before paper end	little paper	paper OK
	1	1:1	paper	present	not present
	2	1:1	temperature	temperature OK	print head too hot/cold
	3	1:1	head	closed	open
	4	1:1	paper jam/cutter	no error	error
	5	on	Rx error	no error	Rx error
	6		always 0		
	7		always 1.		

Mode 2, activated through bit 1 in parameter 23. With every transmission of the error status, two bytes are sent to the host.

Status Byte 2

Bit 6 distinguishes these two bytes:

Bit	LED	Status	0	1
0	on	AUX1 sensor	closed	open
1	on	buffer status	buffer empty	buffer overflow
2	on	factory parameters	valid	invalid
3	on	AUX2 sensor	closed	open
4		unused $= 0$		
5		unused $= 0$		
6		always 1 (distinction t	o error byte 1)	
7		always 1.		

12 Service and Maintenance

Documents for the System GPT-4352(-60)

All additional documents are listed on the Internet at www.oem-printer.com/flash. You can request the software manual SoMAN-D-558 or -E-559 (English) from GeBE via email (sales.ef@gebe.net).

Service (GeBE Technical Support)



For service or questions, please contact: GeBE Elektronik und Feinwerktechnik GmbH

Beethovenstr. 15

82110 Germering Germany www.oem-printer.com Phone: 0049 (0) 89/894141-0

Fax: 0049 (0) 89/8402168 Email: sales.ef@gebe.net

Further Information



Additional information on the printer series is available at www.oem-printer.com/gpt-4352. At this address, you can also find a personal consultant you can turn to with your questions. Or, simply send an email to the GeBE sales team at: sales.ef@gebe.net For orders, you can use this GeBE sales fax number: +49 (0) 89/894141-33

13 Troubleshooting and Recovery

Not every failure means that there is an error with the printer. You will save time and money by recognizing and fixing simple errors on your own.

The following tips are meant to help you with this:

Symptom	Possible Cause	Remedy
Power Supply		
The printer seems to be printing. Paper is transported, but not blackened.	Paper: Wrong side facing the print head. Only one side of the paper can be printed on.	Insert paper correctly. The thermosensitive side should be turned to the outside of the roll (most of the time). Try the finger nail test: Drag the tip of a finger nail across the paper, pressing down. The friction heat causes the thermosensitive side to blacken.
At the beginning of printing, the LED goes out just briefly. The printer only prints a few dots in one line. The paper feed works, but the self test does not. The printer only prints a few characters in one line. If more is entered, it stops printing altogether.	The power supply is not optimal. Cross section of feed line is too weak. Supplied power too low.	Use short feed lines with sufficient thickness. Check all connections for possible transfer resistances. Since high peak currents occur with thermal printers, even the smallest transfer resistances can result in intolerable voltage drops. In this case, no power supply would be strong enough.
Serial Interface		
After a few characters, the printout starts to be incomplete.	The printer buffer is "over-run" (256 bytes), causing a loss of data. The print data transmitter shows no reaction to handshake.	Use or check handshake. (software: Xon/Xoff or hardware: CTS). If necessary: slow down transmission speed, e.g. down to 1,200 baud.
	Interface problem. The transmission is faulty. (Characters of the upper area are printed). Wrong data format is set. Bad ground connection that causes a part of the printing current through the interface	Use correct interface level. (RS232, TTL?). The transmission cable may be too long. Set the correct baud rate through the menu. Check data format. Check and improve ground connection. Feed current through short, thick lines.
The printer prints the wrong characters.	cable. This leads to an increase in potential there, which results in data corruption.	SHOLL, UHOS.

CE Certification

14 CE Certification

The failure-free operation of the printer (assessment criterion A) is achieved, when all printed information remains recognizable in case of a short-term failure, and the printer, on the other hand, automatically returns to its normal functional status afterwards.


Component CE		in particular
Printer	CE	See conformity statement - available on request

Technical Data • Mechanical Dimensions

15 Technical Data

	GPT-4352V.24	GPT-4352USB			
Print procedure	Fixed thermal print line				
Paper / print width	57.5 ± 0.5 mm / 48 mm				
Resolution	8 dots / mm,	384 dots / line			
print speed	up to 5	50 mm/s			
Supply voltage	4.5 - 6	5.6 VDC			
Power consumption	Online: t	yp. 30 mA			
Max. current during printing	Adjustable by command to max. 0.7	A - 6, depending on operating voltage			
Interfaces	RS232 to 460 kbps (optinal TTL) Baud rates: 1,200; 2,400; 4,800; 9,600; 19,200; 38,400; 57,600; 115,200; 230,400; 460,800 Mode: adjustable: 7, 8 data bit, 1,2 stop bits, none, odd, even parity handshake: hardware handshake and XON / XOFF	USB full speed printer class bidirectional			
Data compression	Factor app. 3 :1 (for graphic commands); PC-compatible; Windows driver				
Character sets, cpl	24, 48 selectable by control command				
Bar code	Cod	de 39			
Environment	o °C to 50 °C (-10 °C to +60 °C using GeBE HQ paper) 10% to 80% rel. humidity, no moisture condensation				
MTBF	50 km printed paper (wit	th specified thermal paper)			
Dimensions in mm	GPT-4352: 76.8 x 77.4x 39.3 mm, ET: 27 mm / GPT-4352-60: 76.8 x 111.4 x 72.0 mm, ET: 58.2 mm				
Roll diameter	GPT-4352: max. 31 mm/ app. 11 m with 60 g/m ² GPT-4352-60: max. 60 mm/ app. 40 m with 60 g/m ²				
Weight	GPT-4352: app. 150 g incl. paper roll / GPT-4352-60: app. 260 g incl. paper roll				
Housing material GPT-4352: ABS (various colors available) GPT-4352-60: PA66 - GF15					
Norms	CE: See conformity statement				

16 Mechanical Dimensions



GeBE E+F GmbH • www.gebe.net • GeBE Doc.No.: SMAN-E-627-V0.92 Easy-Loading Thermodrucker GPT-4352(-60)-92